

## GLASS TILE: CLEANING AND MAINTENANCE

A primary benefit of selecting glass tile for an application is its easy maintenance attributes. Regular care and maintenance will help keep tiled surfaces looking their best. Routine cleaning of glass mosaic tile can be done with warm water, any commonly sold light-duty neutral pH glass cleaning product, or any non-abrasive cleaning solutions that are commonly recommended for both glass and tile.

Acid, alkaline, and solvent-based cleaners can damage and/or discolor the tiles and grout and should **NOT** be used.

### INITIAL CLEANING AND MAINTENANCE

The most important step for future maintenance involves the complete removal of any grout haze during the initial installation. This can usually be accomplished by simply scrubbing the surface of the glass using a microfiber cloth, soft bristle brush, or white scrub pad depending on soil load, and hot water mixed with a weak dilution of close-to-neutral pH detergent additive. When clean, thoroughly rinse and dry with a wet/dry vacuum or dry towel.

Grout joints should be treated with a commercially available penetrating type sealer, not film-forming coatings. Follow the sealer manufacturer's recommendations and instructions. For grout joints, it is normally recommended that the joints be initially sealed after curing for 7 to 14 days (see grout manufacturer's recommendations for suggested cure time). The primary purpose of a sealer is to render joints less porous and thereby more stain resistant. The glass tile itself is completely impervious to common stains. Once initial cleaning has been thoroughly completed, our general maintenance procedures can be followed for continuous long-lasting beauty.

### GENERAL MAINTENANCE

General maintenance and cleaning of tile will vary depending on the surface texture and soil load. Sweeping or vacuuming to remove loose soil or other surface contaminants should be done first, followed by wiping with a slightly damp cloth and clean water. If a more aggressive cleaning process is required, use a neutral pH cleaner followed by a thorough rinsing.

The following five steps are essential for the successful maintenance of glass tile:

1. All spills should be cleaned as quickly as possible.
2. Use only the recommended dilution of detergent. More is not always better; higher concentrations of detergent in the cleaning solution will only make it more difficult to rinse.
3. Allow the proper dwell time. The detergent solution must be given time (5-10 minutes) to act on the soil load. Always follow label instructions on all products used.
4. Scrub with a white scrub pad or soft bristle brush.
5. Rinse thoroughly with clean, clear water to remove the dirty detergent solution and soil. Rinsing is an important step in the maintenance procedure. If dirty detergent solution is not removed and is allowed to dry on the surface, a coating may form which is very difficult to remove. Completely remove the rinse water with a clean dry mop or microfiber towel.

**Questions?** Please contact our Technical Services Department at [TechnicalServices@LunadaBayTile.com](mailto:TechnicalServices@LunadaBayTile.com)

[www.LunadaBayTile.com](http://www.LunadaBayTile.com)

**Lunada Bay Tile** provides product information and information concerning installation procedures and maintenance practices to assist each of its customers in making selection, usage, installation and maintenance decisions. Customer's selection and usage of Lunada Bay Tile products and the installation procedure and maintenance practice employed by each customer are outside the direction and control of Lunada Bay Tile and are strictly and entirely the choice and responsibility of each customer and their installer. Lunada Bay Tile does not warrant any product for any specific use, nor any installation procedure or maintenance practice, and expressly disclaims all asserted claims after installation of Lunada Bay Tile products. See website for specific warranty.